



**Residential installation
- home theater**



- : Digital
- : Analog
- : Network

**Residential
installation -
home theater
and third
party control**



-  : IP Control
-  : Digital
-  : Analog
-  : Network

**Pre-Out XLR -->
Euroblock Analog**

Network router

Sonos port or
(Blusound
B100S) - coax
digital out

AES/EBU (in) to
Dante avio
converter

*Note: do not use
the AES/EBU
output*

Zone 1

Zone 2

Zone 3



Network router



POE gigabit switch



--- Ethernet (dante network)

— Ethernet (for app control)

Technical room

Public spaces



Sonos app only



Room 1



Room 2



Room 3

Bluesound B400S
coax digital out

AES/EBU (in) to
Dante avio
converter

*Note: do not use
the AES/EBU
output*



Zone 1

Zone 2

Zone 3

Zone 4



POE gigabit switch

Network router



--- Ethernet (dante network)

— Ethernet (for app control)

Technical room

Public spaces



BluOS app only



Room 1



Room 2



**Wall panel
volume Ctrl**



Room 3

Commercial installation - multiple sources & multiroom audio to Dante network

Source 1: audio streamer



RCA > Euroblock



Source 2: DJ mixer



XLR > Euroblock



Matrix mixer - Digital Signal Processor (dante compatible)



POE gigabit switch



- : Ethernet (Dante Network)
- : Ethernet (Network & IP Ctrl)
- : Analog

Network router



Technical room
Public spaces



Zone 1



Wall panel:
Volume Ctrl, Analog Jack



Wall panel:
Volume Ctrl, Analog Jack



Zone 2

Source 1: audio streamer



Source 2: DJ mixer



Network router



RCA > Euroblock



XLR > Euroblock



Analog Signal Processor

— : Ethernet

→ : Analog

Technical room

Public spaces



Zone 1



Zone 1 Volume Ctrl



Zone 2 Volume Ctrl



Zone 2



Source 1: audio streamer

Source 2: DJ mixer



DANTE Signal Processor



XLR > Euroblock



RCA > Euroblock



Network router



POE gigabit switch



Automation Controller (Crestron/C4/Savant)

-  : IP Control
-  : Ethernet (Dante Network)
-  : Ethernet (Network & IP Ctrl)
-  : Analog

Technical room
Public spaces



Zone 1

Zone 1 Volume Ctrl



Zone 2 Volume Ctrl

Zone 2